





871
Fruit basket
Obstschale
cm. 24 X 11






416
Finger food tray
Finger Food Tablett
cm. 20 X 20






417
Bread/Bread sticks basket
Brot- und Grissinikorb
cm. 26 X 12






422
Amouse buche tray
Amouse buche Tablett
cm. 20 X 10






404
Bread tray/Bottle coaster
Brot Tablett/Flaschenteller
cm. 12,5 X 12,5





428
Charger
Platzteller
Ø cm. 34






596
Fretworked baskets
Früchtekorb gelocht
Ø cm. 16,8 - H cm. 11
cl. 150





439
OVO
Ice-bucket
Eisgefäß
Ø cm. 11 - H cm. 13
cl. 100






599
Fretworked baskets
Früchtekorb gelocht
Ø cm. 29 - H cm. 18,5
Lt. 8





870
Bread / Bread sticks holder
Brot und-Grissini -Schale
cm. 35,5 X 11





598
Basket
Früchtekorb
Ø cm. 29 - H cm. 18,5
Lt. 8

